

FORD MAVERICK FLAT TOW SETUP

1. **Start** engine, **FULLY** press throttle to engage ICE
2. Foot **ON Brake**, shift to **Drive** then **Reverse** then **Neutral**
3. Foot **OFF Brake**
4. **Stop** engine
5. Put in **Accessory** mode (foot OFF Brake, **Start/Stop Button**)
6. Clear screen prompts with **OK** button
7. Press **Menu** button
8. On **Settings** press **OK**
9. On **Vehicle** press **OK**
10. **Scroll** down to **Neutral Tow**, press **OK**
11. **Hold down OK** until finished
12. **FULLY** press Brake
13. Shift to **Neutral**
14. Put AC in **Recirculated** (Rec)
15. Foot **OFF Brake**
16. **Press Start/Stop** button (Accessory Off)
17. Dash will **confirm** "**Neutral Tow Mode**"
18. Set up RVI /Brake Buddy
19. Lock Doors

SWITCHING OFF NEUTRAL TOW

1. Remove RVI / Brake Buddy
2. Put in **Accessory** mode (foot OFF Brake, **Start/Stop Button**)
3. **FULLY** press **Brake**
4. Shift to **Park**
5. Dash will **confirm** “**Neutral Tow Mode OFF**”

NOTES:

1. If driving 6 hours or more a day, switch off Neutral Tow Mode and restart setup !!!
2. Do NOT exceed 70 mph !!! !!!