

2022-2024 Ford Maverick Forscan Coding List By EONR24

|                     |                                   |                                                       |                                           |
|---------------------|-----------------------------------|-------------------------------------------------------|-------------------------------------------|
| * = AS BUILT Coding | EZ = Plain English (Non-AS BUILT) | Change Value to the RED digit and ignore BLACK "xxxx" | MAKE SURE TO BACKUP YOUR FACTORY CODINGS! |
|---------------------|-----------------------------------|-------------------------------------------------------|-------------------------------------------|

| Function                                                                        | Module | Instructions / Address                                                      | Coding |        |        | Notes                                                                                                                     |
|---------------------------------------------------------------------------------|--------|-----------------------------------------------------------------------------|--------|--------|--------|---------------------------------------------------------------------------------------------------------------------------|
| Engine Sound Enhancement Disable (2025)                                         | ACM*   | "727-01-01"                                                                 | xxxx   | xxxx   | 1x--   |                                                                                                                           |
| Auto Start/Stop Disable                                                         | PSCM   | (EZ) Disable "Start Stop"                                                   |        |        |        | Disables Auto Start Stop Completely                                                                                       |
|                                                                                 | IPC    | (EZ) Disable "Start Stop"                                                   |        |        |        | (OPTIONAL) Removes Start/Stop icon from cluster                                                                           |
|                                                                                 | HVAC*  | 733-01-05                                                                   | xxxx   | x0xx   | xx--   | (OPTIONAL) Disables Start/Stop button and light                                                                           |
| Double Honk Exiting Running Vehicle Disable                                     | BCM    | (EZ) Disable "Double Honk on Leaving Cabin"                                 |        |        |        |                                                                                                                           |
| Panic Alarm Horn Disable                                                        | BCM    | (EZ) Change "Panic Alarm Mode" to "Lights Only"                             |        |        |        | Only displays lights, no alarm                                                                                            |
|                                                                                 |        | (EZ) Disable "Alarm Horn Sound"                                             |        |        |        | (OPTIONAL)                                                                                                                |
| Radio Data Connectivity Screen Disable (XL,XLT only)                            | ACM*   | "727-08-06"                                                                 | x2xx   | xxxx   | xx--   | MAY CAUSE FORD PASS APP TO STOP WORKING                                                                                   |
| Driver Restriction Menu Disable (XL,XLT only)                                   | ACM    | (EZ) Disable "Driver Restriction Configuration"                             |        |        |        |                                                                                                                           |
| Video Playback enable with NO speed restriction (XL,XLT only)                   | ACM    | (EZ) Change "Video Playback" to "Enabled without Restrictions"              |        |        |        | Enables you to play videos on the radio screen from a USB drive                                                           |
| ST Radio Animation Enable (XL, XLT only)                                        | ACM    | (EZ) Change "Animation Type" to "ST"                                        |        |        |        |                                                                                                                           |
| Navigation in Motion (Lariat only)(USA only)                                    | ACM*   | "727-04-01"                                                                 | xxxx   | xxxx   | 57--   | Removes radio speed restrictions for Nav and USB                                                                          |
|                                                                                 | APIM*  | "7D0-02-01"                                                                 | 57xx   | xxxx   | xx--   |                                                                                                                           |
| Change Radio Animation (Lariat only)                                            | APIM   | (EZ) Change "Splash Screen" to "ST" or other options linked ----->          |        |        |        | <a href="#">Lariat BOOT SCREENS</a>                                                                                       |
| Climate Controls on Radio Touchscreen (Lariat only)                             | APIM   | (EZ) Enable ALL "Climate Overlay" options                                   |        |        |        | WRITE ALL OF THESE CHANGES WITH THE ENGINE ON                                                                             |
|                                                                                 | APIM   | (EZ) Enable "Climate Auto Seats"                                            |        |        |        |                                                                                                                           |
|                                                                                 | APIM   | (EZ) Enable "Climate Domain"                                                |        |        |        |                                                                                                                           |
|                                                                                 | APIM   | (EZ) Change "Seat Button Icons" to "Heated Seats"                           |        |        |        | This adds the Climate Display Tab on the Radio Screen                                                                     |
|                                                                                 | APIM   | (EZ) Enable "Heated Steering Wheel Icon" (if equipped)                      |        |        |        | (Only change if equipped with heated steering wheel)                                                                      |
| ECO Coach MyView Enable                                                         | IPC    | (EZ) Enable "ECO Mode"                                                      |        |        |        |                                                                                                                           |
|                                                                                 | IPC    | (EZ) Enable "ECO Coach Feature"                                             |        |        |        |                                                                                                                           |
|                                                                                 | IPC    | (EZ) Enable "ECO Coach with Efficient Drive Mode"                           |        |        |        |                                                                                                                           |
| Heated Steering Wheel Temp Adjust (if equipped)                                 | SCCM   | (EZ) Change "Heated Steering Wheel Temperature" value to degrees Celsius    |        |        |        |                                                                                                                           |
| Heated Seats L/R Temp Adjust (if equipped)                                      | HVAC   | (EZ) Change "Heated Seats L/R Temperature" value to degrees Celsius         |        |        |        |                                                                                                                           |
| Traffic Sign Recognition (TSR) Enable                                           | IPC    | (EZ) Enable OR Disable "Traffic Sign Recognition (TSR)"                     |        |        |        | DISABLE on 4in Cluster, ENABLE on 6.5in Cluster, Try Both                                                                 |
|                                                                                 | IPC    | (EZ) Enable "Speed Limit Info Function (SLIF)"                              |        |        |        | Disable = European Signs, Enable = USA Signs (4in ONLY)                                                                   |
|                                                                                 | IPMA   | (EZ) Change "TSR" to "Speed Limit Info Function (SLIF)"                     |        |        |        |                                                                                                                           |
|                                                                                 | IPMA   | (EZ) Change "Traffic Sign Recognition Mode" to Camera Data Only"            |        |        |        |                                                                                                                           |
| TSR MAY DELAY OR INTERFERE WITH PRE COLLISION ASSIST WARNING ON 4 INCH CLUSTERS |        |                                                                             |        |        |        |                                                                                                                           |
| Extra Drive Modes Enable                                                        | ABS    | (EZ) Disable SDM - ABS                                                      |        |        |        |                                                                                                                           |
|                                                                                 | ABS    | (EZ) Enable SDM - Mode 9 (Sand) , Enable SDM - Mode 8 (Ruts) (NON-FX4)      |        |        |        | Clear DTCs if any                                                                                                         |
|                                                                                 | ABS    | (EZ) Enable SDM - Mode 4 (Eco) , Enable SDM - Mode 2 (Sport) (FX4)          |        |        |        | Clear DTCs if any                                                                                                         |
| All Windows Up/Down with Key Fob Enable (Lariat only)                           | BCM    | (EZ) Enable "Global Close - Vehicle", Enable "Global Close - Initial Value" |        |        |        | Open windows: short press unlock button, then long press (3+sec)                                                          |
|                                                                                 | BCM    | (EZ) Enable "Global Open - Vehicle", Enable "Global Open - Initial Value"   |        |        |        | Close windows: long press lock button (3+sec).                                                                            |
|                                                                                 | BCM    | (EZ) Enable "Global Window Close with Remote"                               |        |        |        |                                                                                                                           |
|                                                                                 | BCM    | (EZ) Enable "Global Window Open with Remote"                                |        |        |        |                                                                                                                           |
|                                                                                 | DDM    | (EZ) Enable "Global Close"                                                  |        |        |        | WINDOW RESET MAY BE NEEDED SEE VIDEO BELOW                                                                                |
|                                                                                 | PDM    | (EZ) Enable "Global Close"                                                  |        |        |        | <a href="https://www.youtube.com/watch?v=vOVvPd4cC2Q&amp;t=39s">https://www.youtube.com/watch?v=vOVvPd4cC2Q&amp;t=39s</a> |
|                                                                                 |        |                                                                             |        |        |        |                                                                                                                           |
| Frost Alert Enable                                                              | IPC    | (EZ) Enable "Frost Telltale (Below 5*C)"                                    |        |        |        |                                                                                                                           |
| Seatbelt Menu and Chimes - Disable All                                          | IPC*   | 720-13-01                                                                   | "0000" | "0000" | "0000" | ALL ZEROS                                                                                                                 |
|                                                                                 | IPC*   | 720-13-02                                                                   | "0000" | "0000" |        | ALL ZEROS                                                                                                                 |
|                                                                                 | IPC*   | 720-14-01                                                                   | "0000" | "0000" | "0000" | ALL ZEROS                                                                                                                 |
|                                                                                 | IPC*   | 720-14-02                                                                   | "0000" | "0000" |        | ALL ZEROS                                                                                                                 |
| Seatbelt Menu Disable or Change, keep Chimes/ Dash Light (Alternative)          | IPC*   | 720-13-01                                                                   | "9xxx" | "xxxx" | "xx--" | (Alternative Coding to the prior) #2                                                                                      |
|                                                                                 | IPC*   | 720-13-02                                                                   | "xx1x" | "1x--" |        |                                                                                                                           |
|                                                                                 | IPC*   | 720-14-01                                                                   | "1xxx" | "xxxx" | "xx--" |                                                                                                                           |
|                                                                                 | IPC*   | 720-14-02                                                                   | "xxxx" | "xx--" |        |                                                                                                                           |
| Change Seatbelt Menu Behavior, keep Chimes/ Dash Light (Alternative)            | IPC*   | 720-13-01                                                                   | "xxxx" | "xxxx" | "xx--" | (Alternative Coding to the prior) #3                                                                                      |
|                                                                                 | IPC*   | 720-13-02                                                                   | "xx1x" | "1x--" |        |                                                                                                                           |
|                                                                                 | IPC*   | 720-14-01                                                                   | "1xxx" | "xxxx" | "xx--" |                                                                                                                           |
|                                                                                 | IPC*   | 720-14-02                                                                   | "xxxx" | "xx--" |        |                                                                                                                           |
| Door Ajar Chimes Disable                                                        | IPC*   | 720-01-02                                                                   | xx0x   | xx--   |        |                                                                                                                           |

|                                                                          |      |                                                                           |      |      |      |                                                                                                                                                                                                                                                                                            |
|--------------------------------------------------------------------------|------|---------------------------------------------------------------------------|------|------|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Triple Ding at Start Up Disable                                          | IPC* | 720-01-02                                                                 | xxxx | x2-- |      |                                                                                                                                                                                                                                                                                            |
| Key in Ignition Chime Disable                                            | IPC  | (EZ) Disable "Key Ignition Chime"                                         |      |      |      |                                                                                                                                                                                                                                                                                            |
| Driver Belt Minder Chime                                                 | IPC  | (EZ) Enable or Disable "Chimes - Driver Belt Minder"                      |      |      |      |                                                                                                                                                                                                                                                                                            |
| Mid Passenger Belt Minder Chime                                          | IPC  | (EZ) Enable or Disable "Chimes - Mid Passenger Belt Minder"               |      |      |      |                                                                                                                                                                                                                                                                                            |
| Passenger Belt Minder Chime                                              | IPC  | (EZ) Enable or Disable "Chimes - Passenger Belt Minder"                   |      |      |      |                                                                                                                                                                                                                                                                                            |
| Washer Fluid Warning Disable                                             | IPC  | (EZ) Disable "Low washer fluid warning"                                   |      |      |      |                                                                                                                                                                                                                                                                                            |
| Auto Lock / Auto unlock enable in locking Cluster menu                   | IPC  | (EZ) Enable "Auto Lock" and "Auto unlock"                                 |      |      |      |                                                                                                                                                                                                                                                                                            |
| Adjust Battery Target State of Charge                                    | BCM  | (EZ) Change "Battery Target State of Charge" to desired value (% percent) |      |      |      | Factory = 80% , suggested change 95% (RESET BMS AFTER)                                                                                                                                                                                                                                     |
| All 12v Power Outlets Adjust Cutoff Time                                 | BCM  | (EZ) "Power Point Timeout Enable", Adjust "Power Point Timeout s"         |      |      |      | Timeout is calculated in seconds, Factory is 4500s = 1hr15min                                                                                                                                                                                                                              |
| Rear Tail Light DRL During Daytime Disable (Lariat Only)                 | BCM  | (EZ) Disable "DRL include park lamps"                                     |      |      |      |                                                                                                                                                                                                                                                                                            |
| Headlight Switch/Dial Default to "Last Known Position" instead of "Auto" | BCM* | 726-27-05                                                                 | 1xxx | xxxx | xx-- | Factory coding is "0"                                                                                                                                                                                                                                                                      |
| Police Dark Mode Enable                                                  | BCM  | (EZ) Enable "Police Dark Mode"                                            |      |      |      |                                                                                                                                                                                                                                                                                            |
| DRL to Turn Signals 100% while in Drive (XL,XLT only) (CAUSES DTCs)      | BCM  | (EZ) Change "Left Front High Beam Usage" to "High Beam"                   |      |      |      | <a href="#">LINK TO THREAD WHERE THIS WAS FOUND</a>                                                                                                                                                                                                                                        |
|                                                                          | BCM  | (EZ) Change "Left Front Low Beam Usage" to "Low Beam Only"                |      |      |      | MAY CAUSE DTCs (no check engine light)                                                                                                                                                                                                                                                     |
|                                                                          | BCM  | (EZ) Change "Left Front Position Lamp Usage" to "Position and Park"       |      |      |      |                                                                                                                                                                                                                                                                                            |
|                                                                          | BCM  | (EZ) Change "Left Front Turn Lamp Usage" to "Turn and DRL"                |      |      |      | "TURN ONLY" if using Switchbacks LEDS                                                                                                                                                                                                                                                      |
|                                                                          | BCM  | (EZ) Change "Right Front High Beam Usage" to "High Beam"                  |      |      |      |                                                                                                                                                                                                                                                                                            |
|                                                                          | BCM  | (EZ) Change "Right Front Low Beam Usage" to "Low Beam Only"               |      |      |      |                                                                                                                                                                                                                                                                                            |
|                                                                          | BCM  | (EZ) Change "Right Front Position Lamp Usage" to "Position and Park"      |      |      |      |                                                                                                                                                                                                                                                                                            |
|                                                                          | BCM  | (EZ) Change "Right Front Turn Lamp Usage" to "Turn and DRL"               |      |      |      | "TURN ONLY" if using Switchbacks LEDS                                                                                                                                                                                                                                                      |
|                                                                          | BCM  | (EZ) Disable "Using Low Beam with DRL"                                    |      |      |      |                                                                                                                                                                                                                                                                                            |
|                                                                          | BCM  | (EZ) Disable "Using High Beam with DRL"                                   |      |      |      | Default USA                                                                                                                                                                                                                                                                                |
|                                                                          | BCM  | (EZ) Change "Low Beam Outage" to "None"                                   |      |      |      |                                                                                                                                                                                                                                                                                            |
|                                                                          | BCM  | (EZ) Enable "DRL include park lamps"                                      |      |      |      |                                                                                                                                                                                                                                                                                            |
|                                                                          | BCM  | (EZ) Change "Dim DRL with Low Beam Outage" to "Inhibited"                 |      |      |      | Default USA                                                                                                                                                                                                                                                                                |
|                                                                          | BCM  | (EZ) Enable "DRL by Autolamps - Initial Value"                            |      |      |      | Default USA                                                                                                                                                                                                                                                                                |
|                                                                          | BCM  | (EZ) Enable "DRL by Autolamps - Personal 1-4"                             |      |      |      | Default USA                                                                                                                                                                                                                                                                                |
| Disable Front Turn Signal Hyper Flash for LED switchbacks                | BCM  | (EZ) Disable "Front Bulb Turn Outage"                                     |      |      |      | ALSO REMOVES DTCs FOR TURN SIGNALS AS DRL MOD                                                                                                                                                                                                                                              |
| Disable Hyper Flash for LED Rear Brake Lights / Turn Signals             | BCM  | (EZ) Disable "Rear Stop Outage Indicator"                                 |      |      |      |                                                                                                                                                                                                                                                                                            |
| DRL MENU Enable (CANADIAN MAVERICKS)                                     | IPC  | (EZ) Enable "Daytime Running Lamps Menu"                                  |      |      |      | Default USA                                                                                                                                                                                                                                                                                |
|                                                                          | BCM  | (EZ) Enable "DRL include park lamps"                                      |      |      |      |                                                                                                                                                                                                                                                                                            |
| Silent Mode Enable (XL,XLT only)                                         | BCM  | (EZ) Enable "Silent (Dark) Mode - Vehicle"                                |      |      |      |                                                                                                                                                                                                                                                                                            |
|                                                                          | IPC  | (EZ) Enable "Silent Mode Control Function"                                |      |      |      | Enables on/off for Silent Mode MENU in Vehicle Settings                                                                                                                                                                                                                                    |
|                                                                          | BCM  | (EZ) Enable "Silent (Dark) Mode - Initial Value"                          |      |      |      | Makes Silent Mode On by Default upon start up                                                                                                                                                                                                                                              |
|                                                                          | BCM  | (EZ) Enable "Silent (Dark) Mode - Personal 1-4"                           |      |      |      | (OPTIONAL)                                                                                                                                                                                                                                                                                 |
| Turn by Turn Navigation Enable in Cluster (Lariat only)                  | IPC  | (EZ) Enable "Turn By Turn Navigation"                                     |      |      |      | (Currently Only working with Android Auto , Google Maps)                                                                                                                                                                                                                                   |
| Average Speed Display Enable (Ecoboost Only) (6.5 inch cluster only)     | IPC* | "720-01-01"                                                               | xxxx | x6xx | xx-- |                                                                                                                                                                                                                                                                                            |
| Average Speed Display Enable (Hybrid Only) (6.5 inch cluster only)       | IPC* | "720-01-01"                                                               | xxxx | x4xx | xx-- |                                                                                                                                                                                                                                                                                            |
| Off Road Screen Enable (6.5 inch cluster only)                           | IPC* | 720-07-02                                                                 | x7xx | xx-- |      |                                                                                                                                                                                                                                                                                            |
|                                                                          |      |                                                                           |      |      |      |                                                                                                                                                                                                                                                                                            |
| 4 INCH CLUSTER ONLY                                                      |      |                                                                           |      |      |      |                                                                                                                                                                                                                                                                                            |
| Average Speed Display Enable (TRIP 1, 2) (4 inch cluster only)           | IPC  | (EZ) Enable "Average Speed Display"                                       |      |      |      |                                                                                                                                                                                                                                                                                            |
| Cluster Settings Menu Speedlock Disable (4 inch cluster only)            | IPC* | 720-17-01                                                                 | 4xxx | xxxx | xx-- |                                                                                                                                                                                                                                                                                            |
| Change Audio, Phone and Nav screens (4 inch cluster only)                | IPC* | 720-17-01                                                                 | xxxx | xx?x | xx-- | F = Enable All Screens , 0 = Disable All Screens                                                                                                                                                                                                                                           |
| Trip/Audio MyView Enable (4 inch cluster only)                           | IPC* | 720-17-01                                                                 | xxxx | xxx8 | xx-- |                                                                                                                                                                                                                                                                                            |
| (FP) Ford Performance MyView Enable (4 inch cluster and Ecoboost only)   | IPC* | 720-17-01                                                                 | xxxx | xxxx | x6-- |                                                                                                                                                                                                                                                                                            |
| Launch Control on (FP) MyView Enable (4 inch cluster and Ecoboost only)  | IPC* | 720-17-02                                                                 | ?xxx | xx-- |      | 0= LCCL OFF (OEM), 1= LCCL 2500rpm, 2= LCCL 2600rpm<br>3= LCCL 2700rpm, 4= LCCL 2800rpm, 5= LCCL 2900rpm<br>6= LCCL 3000rpm, 7= LCCL 3100rpm, 8= LCCL 3200rpm<br>9= LCCL 3300rpm, A= LCCL 3400rpm, B= LCCL 3500rpm<br>C= LCCL 3600rpm, D= LCCL 3700rpm, E= LCCL 3800rpm<br>F= LCCL 3900rpm |
|                                                                          | IPC  | (EZ) Enable "Launch Control"                                              |      |      |      |                                                                                                                                                                                                                                                                                            |
| Change Default MyView Screen (4 inch cluster only)                       | IPC* | 720-17-02                                                                 | x?xx | xx-- |      | 0 = Digital Speedo (OEM) , 1 = Fuel Economy, 2 = Trip/Audio ,<br>3 = Calm Screen , 4 = Eco Coach , 5 = Ford Performance                                                                                                                                                                    |
|                                                                          |      |                                                                           |      |      |      |                                                                                                                                                                                                                                                                                            |

| ADD ONS Below (May Require Installation of Parts)                           |        |                                                                       |      |      |      |                                                                                          |
|-----------------------------------------------------------------------------|--------|-----------------------------------------------------------------------|------|------|------|------------------------------------------------------------------------------------------|
| Lane Keep Assist (LKA) Coding (Non Co-Pilot360) (XL only, w/ stalk install) | IPC*   | "720-01-02"                                                           | x2xx | xx-- |      | Factory digit for non co pilot is a 0 (enables Driver alert system)                      |
|                                                                             | IPC*   | "720-02-01"                                                           | xxEx | xxxx | xx-- | Factory digit for non co pilot is a C (enables Lane assist)                              |
|                                                                             | IPC*   | "720-09-01"                                                           | xxxx | xxxx | x9-- | Factory digit for non co pilot is a 8 (enables Lane assist Haptic)                       |
|                                                                             | IPC*   | "720-10-01"                                                           | 1xxx | xxxx | xx-- | (OPTIONAL) Factory Digit is 0 (enables cross traffic alert)                              |
|                                                                             | PSCM*  | "730-02-02"                                                           | FFFF | xxxx | xx-- | Enables Lane keep assist and Lane departure warning                                      |
|                                                                             | IPMA*  | "706-01-01"                                                           | xxxx | x9Cx | Bx-- | <a href="#">LINK TO ORIGINAL THREAD</a>                                                  |
|                                                                             | SCCM*  | "724-02-01"                                                           | xx58 | 6xxx | xx-- | Steering wheel buttons WITH CRUISE CONTROL #1                                            |
|                                                                             | SCCM*  | "724-02-01"                                                           | xx28 | Axxx | xx-- | Steering wheel buttons WITHOUT CRUISE CONTROL #2                                         |
| Lane Keep Assist (LKA) Coding (Non Co-Pilot360) (XL only, no stalk install) | IPC    | (EZ) Change "Lane Assist" to "2- LDW + Lane Keep Assist"              |      |      |      | Enables Driver Assist Screen and Menu                                                    |
|                                                                             | IPC    | (EZ) Enable "Lane Assist Haptic Intensity"                            |      |      |      | Enable Intensity Option in Lane Keeping System Menu                                      |
|                                                                             | IPC    | (EZ) Enable "Lane Assist Sensitivity"                                 |      |      |      | Enables Lane Keeping System Menu Option                                                  |
|                                                                             | IPC    | (EZ) Enable "Lane Keep System Warning"                                |      |      |      |                                                                                          |
|                                                                             | IPC    | (EZ) Enable "Driver Alert System (DAS)"                               |      |      |      |                                                                                          |
|                                                                             | IPMA   | (EZ) Enable "Customer Preferences - Lane Keep Setting - Personal 1-4" |      |      |      |                                                                                          |
|                                                                             | IPMA   | (EZ) Enable "Customer Preferences - Lane Keep Setting - Vehicle"      |      |      |      |                                                                                          |
|                                                                             | IPMA   | (EZ) Enable "Customer Preferences - Lane Keep Support - Personal 1-4" |      |      |      |                                                                                          |
|                                                                             | IPMA   | (EZ) Enable "Customer Preferences - Lane Keep Support - Vehicle"      |      |      |      | Enables LKS if physical button not present (left stalk)                                  |
|                                                                             | IPMA   | (EZ) Change "Lane Assist" to "3 - LDW + Lane Keep Assist"             |      |      |      |                                                                                          |
|                                                                             | IPMA   | (EZ) Enable "Driver Alert System - Vehicle (DAS)"                     |      |      |      |                                                                                          |
|                                                                             | PSCM   | (EZ) Enable "Lane Departure Warning"                                  |      |      |      |                                                                                          |
|                                                                             | PSCM   | (EZ) Enable "Lane Keep Assist (LKA)"                                  |      |      |      |                                                                                          |
|                                                                             | SCCM   | (EZ) Enable "Lane Keep Assist (LKA)"                                  |      |      |      |                                                                                          |
| Cruise Control on Factory Steering Wheel after button install (XL only)     | SCCM*  | "724-02-01"                                                           | xx58 | 4xxx | xx-- | Works for XL Hybrids and Ecoboosts! (586 if you have LKA)                                |
|                                                                             | IPC    | (EZ) Enable "Cruise Control Switch"                                   |      |      |      | Link to Install Video Below                                                              |
|                                                                             | ABS    | (EZ) Change "Cruise Control" to "Cruise Control"                      |      |      |      | <a href="#">Cruise Control Install XL</a>                                                |
|                                                                             | BCM    | (EZ) Enable "Cruise Control"                                          |      |      |      |                                                                                          |
| Cruise Control Enable after installing Escape Steering Wheel (XL only)      | SCCM   | (EZ) Change "Steering Wheel Switch Right" to "1"                      |      |      |      | Ford Escape steering wheel used with this coding!                                        |
|                                                                             | SCCM   | (EZ) Change "Steering Wheel Switch Left" to "11"                      |      |      |      |                                                                                          |
|                                                                             | IPC    | (EZ) Enable "Cruise Control Switch"                                   |      |      |      |                                                                                          |
|                                                                             | ABS    | (EZ) Change "Cruise Control" to "Cruise Control"                      |      |      |      |                                                                                          |
|                                                                             | BCM    | (EZ) Enable "Cruise Control"                                          |      |      |      |                                                                                          |
| 2020 Escape Titanium Steering Wheel                                         | SCCM*  | "724-02-01"                                                           | x390 | 6xxx | xx-- | Verified on 2022 Maverick XL w/ CP360<br>LINK TO POST BELOW<br><a href="#">POST LINK</a> |
| Paddle Shifter coding after install (Ecoboost only)                         | PCM    | (EZ) Change "Select Shift Transmission" to "Equipped"                 |      |      |      |                                                                                          |
|                                                                             | IPC    | (EZ) Enable "Gear Shift Indicator"                                    |      |      |      |                                                                                          |
|                                                                             | IPC    | (EZ) Enable "Select Shift Tech"                                       |      |      |      |                                                                                          |
| Add Hill Descent Control after install (6.5inch Cluster and Ecoboost only)  | IPC    | (EZ) Enable "Hill Descent Control"                                    |      |      |      |                                                                                          |
|                                                                             | ABS    | (EZ) Enable "Hill Descent Control"                                    |      |      |      |                                                                                          |
| Perimeter Alarm Control (Ford Perimeter Plus only)                          | IPC    | (EZ) Enable "Perimeter Alarm Control"                                 |      |      |      |                                                                                          |
| Perimeter Alarm Reminder (Ford Perimeter Plus only)                         | IPC    | (EZ) Enable "Perimeter Alarm Reminder"                                |      |      |      | (OPTIONAL) Can also be changed in Alarm settings                                         |
| Flat EQ Enable (Aftermarket DSP/Speaker install only)                       | ACM    | (EZ) Change "EQ Special Mode" to "Flat EQ"                            |      |      |      | This coding is used to send more bass to aftermarket speakers                            |
| F150 Fog Light Switch and Fog light installation                            | BCM    | (EZ) Change "Fog Lamp Switch" to "1-Available"                        |      |      |      | <a href="#">HOW TO THREAD</a>                                                            |
|                                                                             | BCM    | (EZ) Change "Fog Lamp Switch Type" to "1-LIN"                         |      |      |      |                                                                                          |
|                                                                             | BCM    | (EZ) Change "Fog Lamp Usage" to "3-Fog Only"                          |      |      |      | OR 0 - Cornering , 1 - DRL , 2 - DRL and Cornering                                       |
|                                                                             | BCM    | (EZ) Enable "Front Fog Lamps"                                         |      |      |      |                                                                                          |
|                                                                             | BCM    | (EZ) Change "Left Front Fog Lamp Usage" to "4-Fog Only"               |      |      |      | (pin 6) "4 - Fog Only" if connecting BCM to DD harness                                   |
|                                                                             | BCM    | (EZ) Change "Right Front Fog Lamp Usage" to "4-Fog Only"              |      |      |      | (pin 7) "4 - Fog Only" if connecting BCM to DD harness                                   |
|                                                                             | BCM    | (EZ) Change "Using Front Fog with High Beam" to "Allowed"             |      |      |      | (OPTIONAL)                                                                               |
|                                                                             | IPC    | (EZ) Enable "Front Fog Lamps"                                         |      |      |      |                                                                                          |
| Coding for Lariat Headlight installation (XL, XLT)                          | BCM*   | "726-11-04"                                                           | xx2x | xxxx | xx-- |                                                                                          |
|                                                                             | BCM*   | "726-12-02"                                                           | x2xx | xx2x | xx-- |                                                                                          |
|                                                                             | BCM*   | "726-15-02"                                                           | x1xx | xxxx | xx-- |                                                                                          |
| Adaptive Cruise Control (ACC) install (XL,XLT only) (Experimental)          | -----> | <a href="#">HOW TO THREAD</a>                                         |      |      |      |                                                                                          |

| OTHER                                                |         |                                                                                                                                                       |  |  |  |                                                                                                       |
|------------------------------------------------------|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|--|-------------------------------------------------------------------------------------------------------|
| Disable AdvanceTrac Stability Control                | PSCM    | (EZ) Change "ABS TYPE" to "1 -ABS ONLY"                                                                                                               |  |  |  | PRE-Collision and Hill Start Assist will NOT work until the coding                                    |
|                                                      |         |                                                                                                                                                       |  |  |  | is reverted to "2 - ABS+ESC" and the dtc codes are cleared!                                           |
| Radio Backup Camera Delay                            | CLUSTER | Enable delay through Radio Settings --> Vehicle --> Camera                                                                                            |  |  |  |                                                                                                       |
| Disable Double Honk when Locking vehicle             | CLUSTER | Disable through Cluster --> Vehicle Settings --> Locking -->Audible                                                                                   |  |  |  |                                                                                                       |
| Disable Mislock Honk when mislocking/Exiting vehicle | CLUSTER | Disable through Cluster --> Vehicle Settings --> Locking -->Mislock Chirp                                                                             |  |  |  |                                                                                                       |
| Autolock / Autounlock                                | CLUSTER | Enable / Disable through Cluster --> Vehicle Settings --> Locking                                                                                     |  |  |  |                                                                                                       |
| Engineering Test / Diagnostic Mode                   | CLUSTER | Hold down the OK button on the steering wheel and Start Engine at the same time. Continue to hold OK button until the green ET appears on the CLUSTER |  |  |  |                                                                                                       |
| SYNC 3 Diagnostic Mode                               | RADIO   | With Ignition ON, Radio ON and Volume at least 1, HOLD the Next Track Button on the Steering Wheel and Radio                                          |  |  |  | <a href="https://www.youtube.com/watch?v=mgv8wk-h4lk">https://www.youtube.com/watch?v=mgv8wk-h4lk</a> |

| UNTESTED BELOW                                          |     |                                                |  |  |  |                                                                   |
|---------------------------------------------------------|-----|------------------------------------------------|--|--|--|-------------------------------------------------------------------|
| Remote Start heated Driver Seat enable (if equipped)    | IPC | (EZ) Enable Remote Start Heated Driver Seat    |  |  |  |                                                                   |
| Remote Start heated Passenger Seat enable (if equipped) | IPC | (EZ) Enable Remote Start Heated Passenger Seat |  |  |  |                                                                   |
| Remote Start heated Steering Wheel enable (if equipped) | IPC | (EZ) Enable Remote Start Heated Steering Wheel |  |  |  |                                                                   |
| Remote Start heated mirrors enable (if equipped)        | IPC | (EZ) Enable Remote Start Heated Mirrors        |  |  |  |                                                                   |
| Emergency Brake Lamp Enable                             | BCM | (EZ) Enable "Emergency Brake Lamp"             |  |  |  | Triple flash brake lights on hard braking and hazard lights after |
|                                                         |     |                                                |  |  |  |                                                                   |
|                                                         |     |                                                |  |  |  |                                                                   |

LINK TO UK RELATED CHANGES BELOW by @RADIODOC

[UK CHANGES](#)

LINK TO MAVERICK LIVNITUP SPREADSHEET BELOW

[LIVNITUP MAVERICK MODULE DECODE SPREADSHEET](#)

LINK TO F150 SYNC 3 APIM DECODING FOR LARIATS

[APIM DECODE F150](#)

LINK TO FORSCAN TWEAKS TO IMPROVE AUDIO BELOW

[FORSCAN TWEAKS FOR AUDIO UPGRADES](#)

LINK TO GET YOUR FACTORY FORD CODINGS BELOW

[FACTORY AS BUILT CODINGS](#)

LINK TO FORSCAN TUTORIAL AND GUIDE ON GETTING STARTED BELOW

[LIVNITUP FORSCAN GUIDE](#)

|                   |
|-------------------|
|                   |
| <b>CREDIT TO</b>  |
| "@LIVNITUP"       |
| "@TOINKY"         |
| "@RADIODOC"       |
| "@MAVERICK2022XL" |
| "@OREOMUFFIN"     |
| "@DALLASMAVERICK" |
| "@VTEC87PRI"      |
| "@OLD_NORM"       |
| "@SNOWCATXX87"    |
| "@MAVRIK23"       |
| "@JERRISN"        |
| "@DOGCMP6"        |
| "@DOC928"         |
| "@TYVEMATTIS"     |
| "@THESHARK"       |
| "@PASTOR_ZATX"    |
| "@MAVERICK OCD"   |
| "@CAPTBANANA"     |
| "@ZOODAD"         |

|                           |
|---------------------------|
| "@CAPTBANANA"             |
| "@EONR24"                 |
| "@THEX"                   |
| "@TRAILMASTER"            |
| "@PACKER BILL"            |
| "@DEWEYORDEWEYNOT"        |
| "@TELEMACHUS"             |
| "@ADMINISTRATOR"          |
| "@RYAN2366"               |
| "@WHOKNEW1985"            |
| "@DMAT"                   |
| "@ROKAN"                  |
| "@GREGK"                  |
| "@INLINE_FIVE"            |
| "@AUTOMATE"               |
| "@NICOBONIS"              |
| "@FIRSTSERGEANT"          |
| "@UBERGADGETFREAK"        |
| "@DADDIO211"              |
| "@MAVERICK2023"           |
| "@COLINL"                 |
| "@MAVMAN321"              |
| "@24ATLASMAVERICK"        |
| "@SKINNYBOY"              |
| "@MATTNC"                 |
| "@CHARLIE950"             |
| "@ELDRICK1"               |
| "@RUGGYBUGGY"             |
| "@BOHEFUS"                |
| "@SILVER23"               |
| "@NHMAVERICK"             |
| "@TWNTYFIVE2LIFE"         |
| "@TONEZORZ"               |
| AND ANYONE ELSE I MISSED! |
|                           |
| UPDATED JUNE 14th, 2025   |

[illegible]



[illegible]

[illegible]





