


# Electric Powertrain Cooling - Component Location



**NOTE:** Coolant temperature will vary with ambient temperature and load. Temperatures shown are for ambient temperature of 50° C (122° F). Red arrows indicate a temperature over 70° C (158° F), Orange arrows indicate a temperature of approximately 70° C (158° F), Blue arrows indicate a temperature below 70° C (158° F).



E314876

Item	Description
------	-------------