

**Passenger compartment fuse box:**

Fuse/Relay N°	Rating	Functions	Shared	12 VDC When Off
1	5A	Not used (spare)	Yes	
2	5A	Not used (spare)		
3	10A	Auto-dimming interior mirror, Image processing module A, Automatic high beam control		
4	10A	Ignition switch, Push button start switch, Key inhibit solenoid		√
5	20A	Lock, Unlock		√
6	10A	Moonroof, DC inverter, Driver door switch pack, Power slide rear window switch		
7	30A	Passenger door module		√
8	5A	Parking assist control module, Trailer brake switch (gas)		
9	5A	Not used		
10	10A	Extended power module		√
11	5A	Telematics control unit module	Yes	√
12	5A	Not used		
13	15A	Driver door lock, Driver door unlock		√
14	30A	Driver door module		√
15	15A	Extended power module		
16	15A	Not used (spare)		
17	15A	SYNC, Receiver transceiver module, Integrated control panel		√
18	7.5A	Wireless accessory charging module	Yes	√
19	7.5A	Not used		
20	10A	Not used (spare)		√
21	7.5A	Climate control, E-shifter module	Yes	?
22	7.5A	Instrument cluster, Smart data link connector, Steering column control module		Recheck
23	20A	Audio unit		√
24	20A	Not used (spare)		√
25	30A	Left-hand front power windows, Right-hand front power windows, Left-hand rear power windows, Right-hand rear power windows		

Engine compartment fuse box:

Fuse/Relay N°	Rating	Functions	Shared	12 VDC When Off	Tapped for...
1	-	Not used			
2	40A	Driveline control module			
3	20A	Horn			
4	40A	Auxiliary heater (hybrid electric vehicle)			
5	-	Not used			
6	-	Not used			
7	60A	Auxiliary heater (hybrid electric vehicle)			
8	-	Not used			
9	40A	Auxiliary heater (hybrid electric vehicle)			
10	30A	Starter motor			
11	15A	Powertrain control module			
12	15A	Powertrain control module			
13	15A	Powertrain control module			
14	15A	Powertrain control module			
15	-	Not used			
16	-	Not used			
17	10A	Air conditioning compressor			
18	10A	Powertrain control module			
19	10A	Anti-lock brake system module			
20	10A	Powertrain control module (hybrid electric vehicle)			
21	5A	Adaptive cruise control			
22	5A	Battery electronic control module (hybrid electric vehicle)			
23	10A	Stoplamp switch			
24	20A	Amplifier			
25	15A	Heated wiper park			
26	10A	Heated windshield camera			
27	-	Not used			
28	-	Not used			
29	-	Not used			
30	-	Not used			
31	-	Not used			
32	30A	Body control module			
33	15A	Heated steering wheel			
34	10A	Front parking aid camera, Forward looking camera, Rear view camera, Blind spot information system			
35	-	Not used			
36	5A	Electronic power assist steering			
37	20A	Trailer tow parking lamps			
38	40A	Blower motor			
39	-	Not used			
40	30A	Aftermarket brake controller			
41	20A	Amplifier			
42	30A	Driver power seat			
43	50A	Electric water pump (hybrid electric vehicle)			
44	40A	Trailer tow module			
45	-	Not used			
46	-	Not used			
47	20A	Heated seats			
48	30A	Trailer tow lighting module battery charge			
49	60A	Anti-lock brake control pump			
50	60A	Cooling fan			
51	30A	Moonroof			
52	5A	Powertrain control module (hybrid electric vehicle)			
53	-	Not used			
54	-	Not used			
55	-	Not used			
56	5A	DC/DC converter (hybrid electric vehicle)			
57	10A	Data link connector			
58	30A	Climate controlled seat module			
59	40A	Body control module			
60	25A	Power sliding rear window			
61	-	Not used			
62	-	Not used			
63	-	Not used			
64	-	Not used			
65	-	Not used			
66	-	Not used			
67	-	Not used			
68	-	Not used			
69	10A	Trailer tow backup lamps			
70	15A	Port fuel injectors			
71	20A	Rear of console power point			
72	20A	Media bin power point			
73	5A	USB charger - floor console - rear			
74	-	Not used			
75	30A	Windshield wiper motor			
76	10A	Heated exterior mirror			
77	40A	Anti-lock brake valves			
78	-	Not used			
79	25A	Left-hand side enhanced exterior lighting module			
80	25A	Right-hand side enhanced exterior lighting module			
81	20A	Fuel pump			
82	-	Not used			
83	40A	Auxiliary power distribution box (hybrid electric vehicle)			
84	20A	Pick-up box power point			
85	60A	Power inverter			
86	-	Not used			
87	-	Not used			
88	-	Not used			
89	-	Not used			